


Logitech Camera Guide Room 4.2

Using the camera with Zoom

*these microphone, speaker, and camera settings are the same for for all video call platforms including Microsoft Teams and Skype.

- 1 Turn on the TV using the remote
- 2 Plug in the HDMI cable to your laptop, from the TV
- 3 Plug in Camera USB cable to your laptop, from the camera on top of the TV
- 4 Select Camera
Click on the arrow next to the video camera icon
 - Select "Logitech Webcam C925e"



- 5 Select Microphone and Speakers

Click on the arrow next to the microphone icon.

- Under Microphone select 'Microphone (logitech Webcam C925e)'
- Under Speakers select 'SAMSUNG (Intel(R) Display Audio)'

